


Setup UPS on TrueNAS

[UPSD.CONF parameters](#)


[UPS.CONF parameters](#)

You can test the service by running `upsc <servicename>` with `<servicename>` being the identifier used to setup the service

- Enable the UPS service



- Configure the UPS service



Revision #3

Created 5 May 2024 09:12:00 by ColtM

Updated 7 August 2024 23:24:39 by ColtM